



Fister 996 Sport Muffler R&R

1. Jack up the rear of the car, or use a lift
2. Loosen the 2 bolts at the cat connection (#29, 17mm wrench) and slide the connection inward. It will only move about 2 inches
3. Reach up over the headers and remove the 3 nuts that hold the muffler bracket to the engine bracket (#16, 13mm wrench.) They are in a triangle pattern. The lower one is kind of hard to see.
4. Push the muffler out into the side of the bumper and it can be wiggled out from below.
5. Set it on the bench and remove the bracket bolts (#24, #25, 13mm) and remove the tip (#22, 16mm wrench)
6. Reverse the steps to reinstall the new muffler. Take note of the new tip clamp orientation. Tip clamp bolt should point inside towards the mounting bracket. Just put a little snug on the tip clamp bolt so you can align the tip after the muffler is installed. You can tighten it down once you position it where you like with a 16" box end wrench.

