

# FISTER

sport exhaust

993 muffler R&R instructions:

1. Jack up rear of car
2. Remove bolt at tip clamp (#9). Remove exhaust tip. 13mm wrenches
3. Remove bolt at cat clamp (#9) (right above tip clamp.) 13mm wrenches.  
Pry open clamp and slide clamp down onto cat piping.
4. Loosen strap bolt all of the way (#2)(6mm allen.) On '95 MY it was a 13mm nut, which is what the drawing shows. After '95 it was a 6mm allen bolt.
5. Lift muffler up to release it from hanging tab and wiggle out from below.
6. Repeat for next side.
7. Reverse steps to install.

