



MOTORSPORTS

Porsche Cayenne Light Bar Instructions

Thank you for choosing [Maddogs Motor Sports](#).

Please read all instructions completely before beginning installation.

Important Safety Information

This installation guide is provided for informational purposes only. Always follow proper safety procedures when working on your vehicle. Maddogs Motor Sports is not responsible for any injury, damage, or loss resulting from improper installation or use of this product.

Professional installation is recommended if you are unfamiliar with vehicle modifications or mechanical work.

Kit Contents

Your Light Bar Kit includes:

- (1) Light Bar Assembly
- (2) Custom Left-Hand Thread Mounting Bolts and Nuts
- (2) PLA Tube End Plugs

Tools Required

- 19mm socket deep well
- Torque Wrench capable of 70 ft lbs and capable of left hand torque



Installation Instructions

Step 1 — Tow Hook Cap Removal

1. Locate and remove the two front bumper tow hook caps.

Step 2 — Install (2) Mounting Bolts

1. Install the two mounting bolts (these are LEFT HAND threaded) and torque to 65 ft-lbs



Step 3 — Install Light Bar

1. Install the light bar and make sure it is seated firmly against the metal bumper support.
2. Install the two left-hand-threaded lock nuts and torque them to 30 ft-lbs. Tighten the nuts only enough to securely fasten the light bar to the vehicle. **DO NOT** overtighten, as this may stretch the bolts.



Step 4 — Install Tube Plugs



Installation Complete!



Maddogs Motor Sports

Grand Rapids, Michigan
www.maddogsmotorsports.com