



Porsche 914 Aluminum Dead Pedal Installation instructions

1. Mount dead pedal to the left of the clutch pedal. You will need to remove the bolt and bracket holding the pedal board down. Line up the mounting hole in the dead pedal and replace the bracket that holds the pedal board and re-tighten.
2. With the dead pedal held in place by the pedal board, adjust the location of the dead pedal to where you want it and drill the two holes for the provided fasteners. Drill the two holes through the inner fender well using a 1/16" drill bit. Before you drill make sure that the tires are turned toward the passenger's side so that the drill bit does not contact the tire.
3. Mount the dead pedal using the supplied M4 screws and lock nuts. Note: Due to variations in tire size and suspension setups, always check the clearance between the tire and the nut and screw in the fender well. It would be a good idea to use some paint or silicon on the holes to help keep moisture out and prevent rust.

Good Luck!

Thank You!
Maddogs Motor Sports
Grand Rapids, Michigan

www.maddogsmotorsports.com