

Installation instructions: EZ701



Installation by an electrician or competent person required.
Wiring must follow IEE wiring regulations.

Isolate electrical supply before commencing installation.

1. Strip the outer sheath of the flex to 40mm.
2. Strip the inner insulation to 8mm as indicated in the connector.
3. Use a screwdriver at the rear to gently release the lid clamps.
4. Lift the lever lid.
5. Insert the stripped cable into the correct colour-coded connector.
6. Push the cable firmly to the backstop.
7. Release the lever lid.
8. Pull test the cable
9. Use the V-grip cable clamp to trap the flex by pushing the outer sheath downwards.
10. Close the lid, pushing down on both rear corners.
11. Repeat for both loop cables and load cable.
12. Click the male and female connectors together.
13. Reinstate the supply.
14. Test for correct operation.



www.ez-fit.co.uk ez-fit Ltd, Peterborough, UK contact@ez-fit.co.uk