

## Farmboy HD Installation Instructions

Please install the Selector Valve, or ensure that your vehicle has auxiliary hydraulic ports, before installing the Farmboy HD. The Rear Lights may or may not have to be moved outward prior to installation. They are not in exactly the same location on each vehicle.

- 1) Remove J-Brackets from the Farmboy HD
- 2) Insert Farmboy HD fully into receiver Hitch and pin completely through
- 3) Slide J-Brackets onto the main rear frame of the Toolcat 5600, the circular bar located under the dump bed. Make sure that the J-Brackets are mounted fully with no space left between them and the circular bar (See Figure 1)
  - a. Ensure that they are mounted between the clevises on the Farmboy HD
- 4) Insert pins through both the clevises and the J-Brackets; then insert a lynchpin through the pin
- 5) Connect the Quick Connect Hydraulic Lines from the Farmboy HD into the auxiliary hydraulic ports

This is where the J-Brackets go



Figure 1

When finished, the Farmboy HD should look like the picture below.



For

more information on the installation of the Farmboy HD, please view our installation instruction video on YouTube, titled "UTV Hitchworks – Installation of the Farmboy HD on the Bobcat Toolcat 5600", email us ([utvhitchworks@gmail.com](mailto:utvhitchworks@gmail.com)) or call 513-260-3705 and we will be happy to help.