



(970)-581-8134

1405 N. Washington Ave

Loveland, CO 80538

Bushing control arm info Sheet

Disclaimer: all work should be performed by qualified personnel. Use of hydraulic presses and like equipment can be dangerous BE CAREFULL!! Coil springs can be dangerous BE CAREFULL!!



Bolts:

Upper: Replace factory bolts with ½" x 3" long G8 bolts, Washers and nuts

Lowers: reuse factory eccentric bolts

Bushing install

Grease sleeve before installing in control arms, then grease each bushing cup after install using provided grease zerks.



Ball Joints:

Uppers bolt in and should be installed as pictured below



Lowers should be installed as pictured below, the ball joint will go approximately ½" deep when pressed from the bottom



All nuts and bolts should be torqued to proper specs

If you have any addition questions or need further clarification feel free to call or text (970)-581-8134

Thank You so much for Your purchase