



PARADICE

Assembly and Use Instructions

Your S46 rink resurfacer arrives in a stowed configuration with minor assembly required before use:

1. Slide the neck of the water distribution "T" into the slot at the top of the frame. Secure the neck into the frame with a firm push until it snaps into place.
2. Attach the smoothing mat by wrapping the Velcro strips through the slots at the bottom of the frame as shown.

For use, follow these simple steps:

1. Remove the handle and water distribution extension from the frame.
2. Install the handle onto the frame by matching the slots on the handle, and slots in the center of the frame. Slide the handle down firmly until it is fully seated and secure in place by pressing the quick release pin through the holes in the frame and handle.
3. Screw the water distribution extension onto the distribution "T".

You are now ready to attach a garden hose and begin making ice.

You may find it helpful to install a quick-connect and/or a shut-off ball valve to the end of your hose for fast and easy operation. Both these items are readily available at your nearest home improvement or hardware store.



Ready for Use (As Assembled)

Using your Ice Rink Resurfacer

Prepare the Surface

Shovel loose snow off the ice. It's OK to let a thin layer of snow fill gaps and cracks. The ParadICE resurfacer will turn it into a solid, flat skating surface.

Create New Ice with the ParadICE Resurfacer

Attach a water source using a standard garden hose to the ParadICE Resurfacer. Start at the furthest edge from the water source and pull the resurfacer in a straight line pattern, like painting a floor.

Stow the ParadICE Resurfacer

Remove the handle and water distribution extension, and reinstall in the stowed



Stowed Configuration