



Installation

- Connect #1 and #2 to HID ballast
- Connect #3 to battery positive
- Connect #4 to battery negative
- Connect #5 to Factory headlight stock harness .

Note:(Only need to connected one side headlight socket)