ENGINEERING KNOWLEDGE

3RD EDITION
2027

COMPOSITE MATERIALS

REVISED & UPDATED

FOR TECHNICAL EDUCATION

PROCESS | THEORY | PROPERTIES




$$\begin{Bmatrix} N \\ M \end{Bmatrix} = \begin{bmatrix} A & B \\ B & D \end{bmatrix} \begin{Bmatrix} \varepsilon^0 \\ \kappa \end{Bmatrix}$$

$$A_{ij} = \sum_{k=1}^{n} (\bar{Q}_{ij})_k (z_k - z_{k-1})$$

$$B_{ij} = \frac{1}{2} \sum_{k=1}^{n} (\bar{Q}_{ij})_k (z_k^2 - z_{k-1}^2)$$

$$D_{ij} = \frac{1}{3} \sum_{k=1}^{n} (\bar{Q}_{ij})_k (z_k^3 - z_{k-1}^3)$$



$$\varepsilon_x(z) = \varepsilon_x^0 + z\kappa_x$$

$$\sigma = \bar{Q}\,\varepsilon$$

$$Q_{11} = \frac{E_1}{1 - \nu_{12}\nu_{21}}$$

$$Q_{22} = \frac{E_2}{1 - \nu_{12}\nu_{21}}$$

$$Q_{12} = \frac{\nu_{12}E_2}{1 - \nu_{12}\nu_{21}}$$

$$Q_{66} = G_{12}$$

INSIDE:
QR LINKED CONTENTS

GABRIELE COLAONI

Gabriele Colaoni

COMPOSITE MATERIALS for TECHNICAL EDUCATION

Process – Theory – Properties

PREVIEW



Zurich, 2027 – 3rd edition

Unauthorized copy or distribution is strictly prohibited

PREVIEW

About this book

Composite materials are now part of everyday industrial reality, from lightweight structures to high-performance products, yet they are still often taught in fragments, without a clear bridge to the workshop and the factory floor.

Composite Materials for Technical Education (Process- Theory- Properties) was written to provide that bridge, offering a structured, practical path that connects fundamentals to real manufacturing and engineering decisions.

- **Who it is for:**

  technical students, early-career technicians, and anyone who needs a clear, practical introduction to composites without oversimplification.

PREVIEW

- **Also ideal for:**

  teachers and technical trainers who want a reliable backbone for lessons, exercises, and lab activities.

- **Useful in industry onboarding:**

  for new hires in production, quality, and industrialization who must quickly learn correct terminology, typical issues, and best practices.

- **For companies transitioning into composites:**

  especially teams coming from metal-mechanical backgrounds who need solid fundamentals and a process-oriented mindset.

- **Role in technical education:**

  to bridge theory and real manufacturing (linking material behavior, processing methods, defects, and design choices to cost, safety, and producibility) so learners can operate confidently in both workshop and engineering environments.

PREVIEW

What you will learn

In this book you will learn how to:

- understand composite materials through the process–structure–property relationship, rather than as isolated topics
- recognize the main manufacturing routes for composites and their implications on quality, cost, and performance
- read composite behaviour from a load-driven perspective, tracing forces before choosing materials or lay-ups
- identify typical manufacturing defects and process limits, and understand how they originate
- move confidently between workshop practice and engineering reasoning, using correct terminology and sound fundamentals
- develop a process-oriented mindset suitable for production, industrialization, and early design decisions

PREVIEW

Throughout the book, QR codes provide direct access to selected external resources for deeper exploration, including authoritative technical references and applied examples.

Readers also have access to an up-to-date materials database, intended to support comparisons, property evaluation, and informed material selection alongside the concepts discussed in the text.

Contents

Process-structure-property interdependence 25
Processability window 30
Classification of manufacturing technologies 32
Essential theoretical recalls 36
Diffusion 36
Solubility 39
Models for thermosetting resins 45
Polymerization mechanisms 49
Gelling 52
Residual stress 53
Pre-compaction 55
Resin flow 57
Reinforcements 58
Models for thermoplastics 60
Crystallization 62
Polymer flow 66
Squeezing 68
Optimal conditions 70
Prepregs 72
Solution-dip impregnation 73
Hot-melt impregnation 75
Film stacking 77
Powder coating 80
Fiber mixing / Hybridization 82
Co-mingling 82

PREVIEW

Coweaving 84
Reinforcement architectures 85
One-dimensional architectures 86
Unidirectionals (UDs) 86
Unidirectional Reinforcements (UD Tapes) 91
Multiple UD-layer preforms 91
Quasi-two-dimensional architectures 94
Woven fabrics 95
Dry preforms 98
Knitted fabrics 100
Non crimped fabrics NCF 102
Two dimensional architectures 104
2D-Braided structures 104
Semi-finished products 106
3D-Woven fabrics 106
Orthogonal non woven structures 109
3D Weaves 110
3D Meshes 112
Parameters and models for prepregs 115
Adhesiveness (Tack) 115
Resin Fluidity 116
Gelation Time 116
Conformability 117
The flow number 118
Absorption ration and resin distribution function 119
Transverse contraction 120
Efficiency of impregnation 121
The autoclave process 124

PREVIEW

The autoclave 129
The lamination 132
Automated cutting 137
Laser projections 139
The Automated Tape Layup (ATL) 141
Autoclave polymerization 144
Process for thermoset matrices 147
Analytical model for thermoset matrices 150
Thermochemical model 153
Fluid dynamics model 160
Diffusive model 164
Modeling of thermal stresses 166
Implementation of the analytical models 168
Analytical model for thermoplastic matrices 169
Consolidation modeling 172
Intimate contact between layers 172
Autohesion 174
Cooling modeling 175
Implementation of the models 177
Sandwich laminates 177
Economical aspect of the autoclave curing 181
Filament winding 186
Windler 195
Reinforcement tensioning 199
The director system 203
The impregnation tank 205
The distributor trolley (eye) 208
The mandrel 210

PREVIEW

Filament winding materials 214
Filament winding process 215
Analytical winding model 222
Matrix consolidation 229
Thermokinetic sub-model 231
Chemical sub-model 231
Rheological sub-model 232
Kinematic winding sub-model 232
Sub-models implementation 233
Automation in filament winding 236
Technological parameters 238
Tape winding 239
Pultrusion 243
The pultruder 244
Materials for pultrusion 247
The pultrusion process 249
Analytical model for thermosetting resins 251
Pultrusion of thermoplastic matrices 255
Technological figures for pultrusion 259
Evolutions of pultrusion 259
Pull-winding 262
Injection Pultrusion 265
Reaction injection pultrusion 268
Injection pultrusion – continuous resin transfer moulding 271
Analytical modelling 274
Energy balance 277
Heat transfer in the laminate 278

PREVIEW

Heat transfer in the mold 279
Chemical balance 280
Polymerization kinetics 281
Implementation of the submodels 281
Injection pressure 282
Speed of pultrusion 286
Laminate heating 288
The gyrotron beam 293
Characteristics of the radiation 297
Vacuum infusion process/molding 300
Autoclave Resin Infusion Moulding 300
Vacuum infusion process 304
Analytical model for compaction 306
Modelling of consolidation 310
Sub-models integration 311
Materials for vacuum infusion 312
Comparison VIP - RTM/VARTM 314
Micro and macro mechanics of composites 321
Micromechanics of unidirectional continuous reinforcement 323
Longitudinal elastic properties 332
Longitudinal tensile strength 341
Longitudinal thermal expansion 346
Elastic properties in transverse direction 347
Tensile strength in transverse direction 353
Thermal expansion in the transverse direction 354
Poisson Coefficients 357
Micromechanics of short fiber composites 360

PREVIEW

Transfer of stresses 361
Prediction of elastic constants 370
Tensile strength 374
Micromechanics of ribbons 380
Macromechanics of the lamina 383
Hooke's law orthotropic 385
Orthotropic lamina with stress along principal axes 389
Elastic matrix for lamina loaded along arbitrary direction 393
Lamination theory 401
Classical theory of laminates 402
Laminate stiffness matrix 405
Particular laminate matrices 410
Symmetrical laminates 410
Laminates with $A13=A23=0$ and orthotopes 411
Laminates with $D13 \approx D23 \approx 0$ 412
Nearly isotropic laminates 412
Calculation of stresses and strains 413
Thermal stress 416
Failure criteria 420
Maximum stress criterion 421
Maximum strain criterion 422
Maximum distortion energy (Tsai-Hill) 423
The Composites Materials Database 429
Synthetic overview: composites in the materials landscape 431
Overview of composites material classes 434
Preferred fiber/matrix combinations and tabular data 436
Selected prepregs 436

PREVIEW

Selected prepregs (cont.) 439
Selected matrix 443
Selected fibers 445
Selected adhesives 446
Selected cores and honeycombs 448
Visual Comparison of Composites Material Properties 451
Chart Index 451
Prepregs: Specific Modulus vs Density 452
Prepregs: Specific Strength vs Density 454
Prepregs: Specific Modulus vs Max Service Temperature 456
Prepregs: Specific Strength vs Specific Modulus 458
Prepregs: E_{11} vs S_{11} 460
Prepregs: Density vs Max Service Temperature 462
Prepregs: Specific Strength vs Max Service Temperature 464
Prepregs: Fiber Volume Fraction vs Specific Modulus 466
Dry Fibers: Specific Strength vs Specific Modulus 468
Cores & Honeycomb: Density vs Specific Compressive Strength 470
Dry Fibers: Density vs Specific Modulus 472
Resins: Max Service Temperature vs Specific Strength 474
Resins: Max Service Temperature vs Specific Modulus 476
Adhesive Pastes: Density vs Max Service Temperature 478
Adhesive Pastes: Specific Strength vs Max Service Temperature 480
Adhesive Pastes: Specific Modulus vs Max Service Temperature 482

PREVIEW

Cores & Honeycomb: Density vs Specific Elastic Modulus 484
Bibliography 486
Scientific publications 488
Web references 490
Glossary 493
Greek characters 494

PREVIEW

Classification of manufacturing technologies

The following diagram builds on the American Composites Manufacturers Association (ACMA) classification and incorporates the newest technologies now available. It reflects a careful, critical review of existing methods but is not exhaustive: industry often employs “hybrid” processes that combine or adapt the techniques shown.

Non-continuous Open-Mold Processes (Atmospheric Pressure)

- **Hand lay-up (HLU)**
  - Long-fiber and short-fiber laminates
  - Manual impregnation
- **Spray-up**
  - Atomized manual spray-up of chopped fibers
  - Atomized automated spray-up
  - Non-atomized spray lamination
- **Filament winding** (e.g. pressure vessels, pipes)
- **Rotational molding / Centrifugal casting** (e.g. hollow structures)

PREVIEW

Non-continuous Closed-Mold (Controlled-Atmosphere, Medium-Pressure or Vacuum)

- **Vacuum-assisted lay-up**
  - Vacuum bag molding / rigid counter-mold
  - Prepreg lamination + vacuum bag + autoclave curing
    - Autoclave-only cures
    - Microwave curing
    - UV beam curing

- **Resin Transfer and Injection**
  - RTM (Resin Transfer Molding)
  - CRTM (Continuous RTM)
  - UVRTM (UV-cured RTM)
  - ARTM (Autoclave-assisted RTM)
  - RIM (Reaction Injection Molding)
    - RRIM (Reinforced RIM)
    - SRIM (Structural RIM)
- **Vacuum Infusion**
  - RFI (Resin Film Infusion)
  - VIM/VIMP/VIP (Vacuum Infusion Molding/Processing)
  - ARIM (Autoclave Resin Infusion Molding)
  - RIFT (Resin Injection under Flexible Tooling)
    - SCRIMP® (Seemann's Composites Resin Infusion Manufacturing Process)
    - VARTM / VARIM (Vacuum-assisted RTM / Infusion)
    - RIRM (Resin Injection Recirculation Molding)
    - RDF / DRDF (RIFT Diaphragm Forming / Double Diaphragm)
    - Membrane-to-membrane infusion
- **Wet Impregnation + Oven Consolidation** (manual or automated)

PREVIEW

Closed-Mold (Controlled-Atmosphere, High-Pressure Processes)

- **Compression Molding**
  - Wet-lay-up compression molding (liquid resin)
- **Sheet & Bulk Molding Compounds** (semi-finished)
  - SMC (Sheet Molding Compound)
  - BMC (Bulk Molding Compound)
  - TMC (Thick Molding Compound)
- **Pultrusion (Continuous Profile Extrusion)**
  - IP (Injection Pultrusion)
  - RIP (Reaction Injection Pultrusion)

The autoclave process

The autoclave curing process for composite materials dates to 1954 and has since established itself as the benchmark method for the fabrication of high-performance laminates. Its widespread use is historically rooted in the aerospace and defense sectors, where structural integrity, weight reduction, and reliability are paramount. Over the decades, the technology has been selectively adopted in aviation, motorsport, premium automotive production, competitive marine applications, and advanced sports equipment, wherever precision and mechanical consistency outweigh processing costs.

Autoclave processing is centered on the consolidation and polymerization of fiber-reinforced prepregs (typically thermosetting systems) under controlled heat and pressure. The laminate stack is vacuum-bagged and placed within a pressure vessel, where it is subjected to a calibrated temperature and pressure cycle. The elevated pressure, usually in the range of 6 to 7 bar, enhances fiber-resin wet-out, promotes gas evacuation, and suppresses the formation of voids or dry spots during cure. The temperature, meanwhile, activates the curing kinetics of the resin, guiding it from a low-viscosity liquid state to a crosslinked solid.

PREVIEW

Despite the solid theoretical foundations of the process (including reaction kinetics, heat transfer equations, and resin rheology models) the practical implementation remains complex due to the large number of interdependent variables. Parameters such as *temperature ramp rates, dwell times, applied pressure, vacuum quality, resin viscosity, tool thermal inertia, part thickness, and fiber architecture* all interact, often non-linearly. As a result, process optimization tends to rely not

only on predictive simulations but also on *empirical calibration,* supported by experimental trials to fine-tune the cycle for each specific laminate geometry and resin system.

A key performance advantage of autoclave curing lies in its ability to minimize void content. Under properly controlled conditions, final void contents are typically maintained below 1%, compared to the 2%–4% often observed in oven-cured or out-of-autoclave (OOA) composites. This substantial reduction in porosity translates into significant gains in mechanical performance, especially in terms of interlaminar shear strength, fatigue resistance, and compression after impact. These properties are critical in load-bearing aerospace structures, where internal defects act as stress concentrators and limit fatigue life.

Void minimization is achieved by exploiting the pressure gradient established during the cure. As the matrix transitions from a low-viscosity to a gelled state, the applied pressure forces the resin to flow through the inter-fiber voids in a direction orthogonal to the laminate plane. This flow carries along trapped air, volatiles, and microbubbles that may originate from lay-up defects or from chemical byproducts during crosslinking. These gases are expelled via breather and vent paths, aided by the vacuum applied inside the bag.

PREVIEW

To enable effective flow and void purging, the starting prepreg system must contain more resin than what will remain in the final cured composite. Typically, aerospace-grade prepregs have an initial resin content of around 35%–42% by weight, which corresponds to approximately 50%–55% by volume, depending on fiber type and architecture. During cure, part of this resin bleeds out or fills minor tool gaps, resulting in a final matrix fraction closer to the desired 30%–35% by volume. This

excess ensures full wet-out and gap filling without risking resin starvation.

The combination of external pressure, precise thermal control, and a sacrificial resin surplus yields composite parts with exceptional surface finish, dimensional stability, and mechanical uniformity. Although autoclave processing is capital-intensive and requires rigorous control of process parameters, its unmatched quality and repeatability make it indispensable for certified aerospace structures, critical defense applications, and experimental platforms where reliability is non-negotiable. Its legacy, refined over nearly seven decades, continues to define the *highest standard* in composite material fabrication.




Figure 54 - Plot of the composites internal porosity vs autoclave pressure




Figure 55 - Plot of the Interlaminar Shear Strength (ISS) vs porosity content in the laminate (experimental data)

PREVIEW

Porosity in composite laminates originates primarily from two sources: gases and vapors entrapped during lay-up, such as air and moisture incorporated into the resin system, and solvent vapors, which often exert a vapor pressure higher than the internal pressure of the autoclave during cure. Both phenomena, if not properly controlled, contribute to void formation and compromise the structural integrity of the final part.

Resin flow control plays a critical role in minimizing porosity and is typically managed by adjusting external pressure at strategic points in the thermal cycle. In thermosetting systems, pressure is increased as soon as the resin begins to chemically polymerize and viscosity rises. This intervention avoids uncontrolled flow and prevents premature resin stiffening that

would trap volatiles. In thermoplastic systems, pressure is applied as the resin reheats and enters its optimal flow range, ensuring adequate consolidation without inducing defects.

During the early stages of cure, the vacuum level inside the bag is usually kept constant, and no major adjustments are made. Recent research confirms that using sufficiently permeable prepregs allows gases and vapors to migrate more easily through the laminate, promoting degassing and leading to low-void-content structures. However, it's essential to emphasize that removal of volatiles must be completed *before* the onset of gelation or consolidation. Once the matrix begins to crosslink or solidify, any remaining bubbles will become permanently trapped within the resin matrix.

The evacuation of entrapped gases is facilitated by a *breather system*, typically composed of porous, multi-layered polyester sheets, often combined with glass fiber layers. These layers serve a dual function: first, as a preferential pathway for gas escape, and second, as a pressure-distribution medium to ensure uniform compaction over the laminate surface. Proper breather design and placement are crucial to ensuring efficient outgassing and consistent pressure application across the entire part surface.

PREVIEW

→ This QR adds a nuanced, experimental perspective: it compares void content and mechanical outcomes across cure routes and layup approaches.

The autoclave

PREVIEW

The autoclave stands as a cornerstone in high-performance composite manufacturing and advanced material processing. It is, in essence, a highly engineered cylindrical pressure vessel, often of considerable size (industrial models can reach diameters of up to 3 meters and lengths exceeding 15 to 50 meters, depending on the application). Its robust design enables it to withstand internal pressures commonly above 10 to 12 bar, with some systems capable of operating at pressures up to 20 bar. Internally, temperatures can be raised to levels exceeding 180°C for standard curing operations, and up to 400°C in aerospace-grade or high-performance thermoplastic processing, such as for PEEK or PEKK matrices.

The vessel is fitted with a heating system, which may rely on electrical resistance elements, oil-based heat exchangers,

or more commonly, direct or indirect gas-fired burners. Heat distribution within the autoclave is crucial: powerful recirculation fans, often placed axially or radially, ensure uniform thermal gradients throughout the pressure chamber, critical to avoid resin-rich zones or uneven consolidation during the curing cycle. Thermocouples placed at strategic locations allow the monitoring of both air and tool temperatures with a resolution on the order of 0.1°C, feeding data continuously to the supervisory system.

To maintain and control pressure, the autoclave is equipped with a high-capacity pumping and venting unit, typically operating with inert gases such as nitrogen. Nitrogen is preferred over air due to its non-reactive properties, which eliminate the risk of oxidative degradation of matrix resins at elevated temperatures. Pressure regulation is automated through proportional valves, maintaining strict tolerances often within ±0.1 bar to ensure process repeatability and conformity to aerospace or defense-grade specifications.

PREVIEW

All critical functions (heating, pressurization, vacuum regulation, and safety interlocks) are managed by a centralized control unit, often running proprietary software developed by OEMs such as ASC Process Systems from Scholz. The system interfaces with programmable logic controllers (PLCs) and incorporates real-time diagnostics, historical data logging, and remote access for supervisory engineers. Modern autoclaves are also compliant with international standards, including ASME Section VIII, PED, and in many aerospace applications, with NADCAP accreditation requirements.

Safety, predictability, and traceability are at the core of autoclave operations. To that end, integrated alarm systems detect anomalies such as over-temperature, over-pressure,

vacuum loss, and power failure. Emergency venting and pressure relief systems, both mechanical and digital, are standard features. The interior of the vessel is frequently lined with stainless steel to resist corrosion from resin volatiles or cleaning solvents, and the loading carts, which carry the composite layups, are typically thermally inert and mechanically stiff to avoid deformations during cure cycles.

Autoclaves remain the gold standard for the fabrication of structural composite parts in aerospace, motorsport, and defense industries. While newer out-of-autoclave (OOA) and resin infusion techniques offer lower-cost alternatives, autoclave curing still delivers unmatched void content control (typically achieving void fractions below 1%) and mechanical performance essential for primary aircraft structures. The precision, and process stability offered by an autoclave are what make it indispensable for parts that must perform reliably under extreme conditions.

PREVIEW




Figure 56 - Internal structure of an autoclave and control system



Figure 57- Autoclave with the charging sled, vacuum tubes and parts before curing

PREVIEW

The lamination

Lamination remains a critical phase in the fabrication of composite materials, and despite the growing interest in automation, manual lamination still represents the most widespread practice across the industry.

Typically entrusted to highly trained technicians, manual lay-up allows for precision in fiber orientation, adaptation to complex geometries, and on-the-fly corrections. While automated solutions such as ATL (Automated Tape Laying) and AFP (Automated Fiber Placement) offer superior consistency and reduced labor intensity, their adoption is limited by substantial capital investment and complex integration requirements. As a result, even in sectors such as aerospace or high-performance automotive, manual lay-

Implementation of the models

PLASTIC is the numerical code developed to solve both the consolidation and crystallization models described earlier. Designed to be lightweight and computationally efficient, it is fully compatible with standard personal computers and enables convergence toward reasonably accurate solutions under typical processing conditions.

Compared to more comprehensive tools like CURE, PLASTIC is inherently less complex, reflecting the simplified nature of the physical models it implements. While it does not account for the full thermochemical and rheological coupling seen in thermoset systems, it provides a practical and reliable framework for analyzing key stages in thermoplastic processing, such as intimate contact evolution and crystallinity development during cooling.

PREVIEW

Sandwich laminates

In the context of manual lay-up using prepregs, it is possible to fabricate complex sandwich structures incorporating honeycomb cores as the central reinforcement element. These structures are widely used in aerospace and high-performance applications due to their excellent stiffness-to-weight ratio. However, the successful manufacturing of such laminates requires precise control of resin flow in the through-thickness direction, especially at the interface between the face sheets and the core. Inadequate control can result in resin starvation, core crush, or void formation.

For this reason, the use of autoclave consolidation remains essential. The autoclave provides uniform pressure and temperature, ensuring that the prepreg layers achieve complete wetting and bonding to the honeycomb core, while also allowing air and volatiles to be evacuated. Only under such controlled conditions can the integrity of the sandwich structure be guaranteed, particularly when dealing with geometrically complex or large-area panels.




Figure 70 - Typical sandwich structure

Non-monolithic structures, such as sandwich laminates, are characterized by internal regions composed of materials that differ structurally from the external faces. These internal materials are often porous or made up of hollow cells with geometrically significant voids. While such architectures offer exceptional stiffness-to-weight ratios, they also introduce complex challenges during the consolidation and curing stages of composite manufacturing.

Two critical failure modes frequently *encountered in the processing* of these structures are:

1. **Core crush** (defined as a compressive collapse during consolidation). This failure mode is especially common in honeycomb sandwich structures. During autoclave curing, resin from the surface prepregs can be drawn into the open cells of the honeycomb, which effectively act as internal reservoirs. This resin depletion leads to a localized reduction in matrix content at the skin-core interface, weakening the area and leaving unsupported fibers directly exposed to the pressure differential between the vacuum bag and the rigid honeycomb. With no continuous resin matrix to support them, these fibers buckle and fail under compression, initiating core crush. The honeycomb core, being highly rigid in the through-thickness direction, does not deform uniformly, concentrating stress at the boundary where fiber bridging occurs.

2. **Transverse compression-collapse of the core.** This failure is more common in sandwich panels with varying thicknesses (such as tapered or stepped geometries). At the transitions between thick and thin sections, the non-uniform application of pressure during consolidation can induce concentrated compressive forces. These loads act in the honeycomb's least resistant direction (typically in-plane or at a diagonal to the cell walls), causing it to collapse like an accordion. This core deformation then translates outward, dragging the external laminate faces inward, leading to buckling, waviness, or even delamination. In these zones, additional shear stresses also arise from relative sliding between adjacent plies, especially where the laminate curvature changes rapidly. However, these shear forces are typically insufficient to counterbalance the collapsing effect.

PREVIEW

A representative example is shown in the following picture illustrating the vulnerable region at the end of a core in a sandwich structure, often the site where both core crush and transverse collapse initiate.

When both failure modes occur simultaneously, the resulting damage can be catastrophic, compromising the mechanical integrity and dimensional stability of the semi-finished part.

To mitigate these issues, several strategies are commonly employed in industry:


- **Reducing autoclave pressure.** Lowering the applied pressure to around 300 kPa helps minimize excessive compaction and resin migration into the core.
- **Limiting prepreg compaction.** By controlling lay-up pressure and avoiding over-squeeze, the risk of resin depletion and fiber bridging is reduced.
- **Enhancing interlaminar friction.** This can be achieved by using grit-impregnated tapes, improving fiber surface roughness, or introducing more tortuous fiber paths (e.g., twisted fibers), although the latter can compromise surface finish and structural uniformity.
- **Increasing core cell density.** Finer cell structures offer better mechanical support and reduce localized stress concentrations.
- **Mechanical stabilization.** In critical regions, edges can be mechanically secured to the mold using pinning or rivet-like features, helping resist unwanted deformation and buckling.
- **Controlled curing profiles.** Modifying temperature ramps, applying stepwise pressurization, or using staged

PREVIEW

consolidation cycles can reduce gradients and improve structural balance across transitions.

Despite the availability of advanced techniques, the most widely adopted and straightforward solution remains the reduction of consolidation pressure, particularly during the initial stages of cure, where the resin is still mobile and the core most vulnerable.

By combining geometrical design awareness with processing adaptations, the industry continues to advance toward producing increasingly reliable and damage-tolerant sandwich structures.



PREVIEW

Figure 71 - Balance of forces in a sandwich during consolidation

Economical aspect of the autoclave curing

Historically, autoclave curing was adopted to satisfy the demand for high-performance composite materials, with little regard for cost efficiency. In the early development stages, the price of a single cured laminate could reach up to $300 per square meter, reflecting the premium placed on mechanical properties, dimensional accuracy, and reliability, especially in aerospace and defense sectors.

Macromechanics of the lamina

A composite sheet reinforced with either unidirectional or bidirectional fibers typically has a thickness ranging from approximately 0.1 mm to 5 mm. It consists of a single layer of reinforcement embedded in a polymeric matrix. Due to its limited thickness and intrinsic mechanical characteristics, a single lamina is generally not sufficient for direct use in structural applications. Instead, it is employed as a building block in the construction of composite laminates—multi-layered structures engineered by stacking and orienting individual plies according to specific design criteria. These criteria include the number of layers, fiber orientation angles, total thickness, and required mechanical performance under given load conditions.

PREVIEW

A comprehensive analysis of a composite laminate must therefore begin with an understanding of the mechanical behavior of the individual lamina, and particularly its constitutive equations. While each lamina is microscopically heterogeneous, exhibiting material variation from point to point due to the discrete nature of fibers and matrix, at the macroscopic scale, where the fiber spacing is negligible compared to the laminate dimensions, it is typically treated as a homogeneous medium. At this scale, the composite also exhibits pronounced anisotropy in its mechanical response.

More precisely, a composite lamina behaves as an orthotropic material, meaning that it possesses three mutually orthogonal planes of material symmetry. In the context of a flat composite ply, these are defined by:

- the mid-plane of the sheet (in-plane behavior),

- the plane normal to the fiber direction, and
- the plane orthogonal to the lamina surface (through-thickness behavior).

In the case of unidirectional reinforcement, the principal material axes are aligned with the fiber direction (longitudinal axis), the in-plane transverse direction, and the through-thickness direction. For bidirectional fabrics (e.g., woven or stitched), the principal axes are aligned with the two orthogonal fiber directions within the plane and the out-of-plane direction.

To better understand the implications of orthotropy, consider a conceptual experiment: applying a uniaxial tensile load to a cube made of an anisotropic material. In a fully anisotropic material, the deformation and creep behavior would vary unpredictably along different directions, and the stress-strain response would lack symmetry. However, in an orthotropic material, three mutually orthogonal axes exist such that loading along any one of these axes induces only normal deformation in the corresponding direction, without coupling effects such as shear or distortion in the symmetry planes.

PREVIEW

These three orthogonal directions, where the material behaves isotropically in each respective plane, are termed the principal material directions (or natural axes of orthotropy). For a composite sheet, this implies that if the external load is applied along one of the principal directions, the resulting deformation will be purely extensional or compressive, and the associated strain state will not involve shearing or torsion in the orthogonal planes. Conversely, if the load is applied along an arbitrary direction that does not coincide with a principal axis, the resulting stress state will include shear components, and deformation will involve both normal and shear strains.

Understanding this behavior is crucial in the design and optimization of composite laminates, especially when tailoring them for complex load paths, where fiber orientation, stacking sequence, and ply thickness must be precisely engineered to meet performance and safety requirements.

Hooke's law orthotropic

Orthotropic materials share with fully anisotropic materials the property that their mechanical response varies with direction, that is, the relationship between applied load and resulting deformation depends on the orientation of that load relative to the material's inherent symmetry axes. However, in each of the principal material directions, an orthotropic body behaves like an isotropic solid: a uniaxial normal stress produces purely normal strain (no shear), and a pure shear or bending moment produces only shear deformation without any accompanying normal strain.

PREVIEW

In three dimensions, any arbitrary stress state at a point in a body can be fully described by nine independent components of the stress tensor, and similarly by nine components of the strain tensor. When the material responds linearly to these loads, the stresses and strains are related by a generalized Hooke's law, which links each of the nine stress components to the corresponding strains through a fourth-order stiffness tensor. In the special case of an orthotropic material, one with three mutually perpendicular planes of symmetry, that stiffness tensor simplifies significantly, but it still embodies the principle that stress and strain are linearly connected in a direction-dependent manner.

$$\sigma_{ij} = \sum_{k,l} E_{ijkl}\varepsilon_{kl}$$

In the case of completely anisotropic material, therefore, the stress-strain bond involves as many as 81 elastic constants $E_{(ijkl)}$ *(i,j,k,l=1,2,3).*

In fact, since the tensors σ_{ij} and ε_{ij} are symmetrical, that is, only 6 components are independent, the independent elastic constants describing the behavior of an anisotropic material are 36.

Thermodynamic considerations, moreover, make it possible to further reduce these constants to only 21. In fact, we have:

$$\frac{\partial U}{\partial \varepsilon_{ij}} = \sigma_{ij} = \sum_{k,l} E_{ijkl}\varepsilon_{kl}$$

PREVIEW

Therefore, by deriving this with respect to the generic strain component ε_{kl} we obtain:

$$\frac{\partial}{\partial \varepsilon_{kl}}\left(\frac{\partial U}{\partial \varepsilon_{ij}}\right) = E_{ijkl}$$

Thus, reversing the order of derivation and taking into account the continuity of the strain functions, we obtain:

$$E_{ijkl} = E_{klij}$$

The above expression indicates a system of 15 independent equations that allows precisely to reduce the constants from 36 to 21.

If the anisotropic material is specifically orthotropic, that is, it admits three mutually orthogonal planes of symmetry then it is easy to show that the relevant constitutive laws involve only 9 independent elastic constants. In fact, denoting the three

principal axes of the material by 1,2,3, since, as noted earlier, the application of a tension σ_{ij} *(i=1,2,3)* produces no distortion ε_{ij} (*i≠j*) must be:

$$E_{ijkl} = 0 \qquad (k \neq l)$$

The preceding represents a system of 9 equations that allows reducing the constants from 21 to 12.

Furthermore, for symmetry with respect to planes 1-2, 1-3, and 2-3, the application of a shear stress σ_{ij} *(i≠j, i,j=1,2,3)* does not produce distortions ε_{kl} (k≠l) in the other planes *(ij≠kl), i*.e., it must also be:

$$E_{ijkl} = 0 \quad (i \neq j, k \neq l, ij \neq kl)$$

Due to the principle of reciprocity of tangential stresses ($\sigma_{ij} = \sigma_{ji}$) the latter relationship simply represents a system of 3 equations that allows us to further reduce the elastic constants from 12 to only 9.

PREVIEW

The elastic constants of an orthotropic material can be advantageously ordered into a 6x6 symmetrical matrix (stiffness matrix), which allows Hooke's law to be written in matrix form as:

$$\begin{bmatrix} \sigma_{11} \\ \sigma_{22} \\ \sigma_{33} \\ \sigma_{12} \\ \sigma_{13} \\ \sigma_{23} \end{bmatrix} = \begin{bmatrix} E_{1111} & E_{1122} & E_{1133} & 0 & 0 & 0 \\ E_{1122} & E_{2222} & E_{2233} & 0 & 0 & 0 \\ E_{1133} & E_{2233} & E_{3333} & 0 & 0 & 0 \\ 0 & 0 & 0 & E_{1212} & 0 & 0 \\ 0 & 0 & 0 & 0 & E_{1313} & 0 \\ 0 & 0 & 0 & 0 & 0 & E_{2323} \end{bmatrix} \cdot \begin{bmatrix} \varepsilon_{11} \\ \varepsilon_{22} \\ \varepsilon_{33} \\ \varepsilon_{12} \\ \varepsilon_{13} \\ \varepsilon_{23} \end{bmatrix}$$

In the case of plane state of tension ($\sigma_{33} = \sigma_{13} = \sigma_{23} = 0$) this relationship can be advantageously simplified as:

$$\begin{bmatrix}\sigma_1\\ \sigma_2\\ \tau_{12}\end{bmatrix}=\begin{bmatrix}E_{11} & E_{12} & 0\\ E_{21} & E_{22} & 0\\ 0 & 0 & E_{33}\end{bmatrix}\cdot\begin{bmatrix}\varepsilon_1\\ \varepsilon_2\\ \gamma_{12}\end{bmatrix}$$

It is then possible, by simple inversion of the stiffness matrix, to obtain the relationship between strains and stresses:

$$\begin{bmatrix}\varepsilon_1\\ \varepsilon_2\\ \gamma_{12}\end{bmatrix}=\begin{bmatrix}S_{11} & S_{12} & 0\\ S_{21} & S_{22} & 0\\ 0 & 0 & S_{33}\end{bmatrix}\cdot\begin{bmatrix}\sigma_1\\ \sigma\\ \tau_{12}\end{bmatrix}$$

The S matrix is named the *compliance matrix*. The significant terms of it are related to the terms of the stiffness matrix by the inversion relations:

$$E_{11}=\frac{S_{22}}{S_{11}S_{22}-S^2{}_{12}};\quad E_{22}=\frac{S_{11}}{S_{11}S_{22}-S^2{}_{12}};\quad E_{12}=\frac{S_{12}}{S_{11}S_{22}-S^2{}_{12}};\quad E_{33}=\frac{1}{S_{33}}$$

PREVIEW

In conclusion, it can be stated that the constitutive equations of an anisotropic material require knowledge of 21 elastic constants (i.e., 6x6 full symmetric matrices), those of an orthotropic material 9 elastic constants (6x6 sparse matrices), which in the plane case are reduced to only 4 (3x3 sparse matrices). In each case there is greater complexity than in the case of isotropic materials that require, for two- and three-dimensional states, only 2 elastic constants E, ν.

All the talk made applies strictly to transversely isotropic orthotropic materials.

Orthotropic lamina with stress along principal axes

When an orthotropic lamina is loaded along its principal axes, its otherwise complex generalized Hooke's law reduces dramatically in complexity. Instead of nine independent stiffness terms, we find that only four material constants are needed to characterize its in-plane behavior: the longitudinal Young's modulus E_L, the transverse Young's modulus E_T, the in-plane shear modulus G_{LT}, and the major Poisson's ratio ν_{LT} (noting that ν_{TL} follows directly from reciprocity and is not independent).

To see how these four constants map onto the entries of the stiffness matrix, we invoke three simple loading cases. First, when the lamina is pulled in tension purely along the fiber direction (the "longitudinal" axis), only E_L and ν_{LT} come into play: the resulting axial strain and lateral contraction can be written explicitly and directly compared to the general matrix form of constitutive equations. Second, a uniaxial pull along the transverse axis isolates E_T (along with the same Poisson ratios), allowing its identification in the matrix. Finally, by applying a pure in-plane shear load, without any normal stress, one measures the lamina's shear deformation, which pins down G_{LT}.

PREVIEW

By matching each of these special-case stress–strain relations to their corresponding rows and columns in the full constitutive matrix, each stiffness coefficient acquires a clear physical meaning. In effect, the process of "calibrating" the matrix entries against these straightforward tests transforms a formal, energy-based expression into a set of parameters that engineers can both measure in the lab and use directly in laminate-level structural analyses.

$$\sigma_L = E_{11}\varepsilon_L + E_{12}\varepsilon_T$$
$$\sigma_T = E_{21}\varepsilon_L + E_{22}\varepsilon_T = 0$$

Which resolved with respect to deformations provide:

$$\varepsilon_L = \frac{E_{22}}{E_{11}E_{22} - E^2{}_{12}}\sigma_L$$
$$\varepsilon_T = -\frac{E_{12}}{E_{11}E_{22} - E^2{}_{12}}\sigma_L$$

Then taking the definitions into account, the di Young's modulus and Poisson's coefficient are derived:

$$E_L = \frac{\sigma_L}{\varepsilon_L} = \frac{E_{11}E_{22} - E^2{}_{12}}{E_{22}}$$
$$\nu_{LT} = -\frac{\varepsilon_T}{\varepsilon_L} = \frac{E_{12}}{E_{22}}$$

On the other hand, considering a uniaxial tension in the transverse direction:

PREVIEW

$$E_T = \frac{\sigma_T}{\varepsilon_T} = \frac{E_{11}E_{22} - E^2{}_{12}}{E_{11}}$$
$$\nu_{TL} = -\frac{\varepsilon_L}{\varepsilon_T} = \frac{E_{12}}{E_{11}}$$

Finally, considering a pure shear stress, we have:

$$\tau_{LT} = E_{33}\gamma_{LT}$$

From which we immediately obtain:

$$G_{LT} = \frac{\tau_{LT}}{\gamma_{LT}} = E_{33}$$

From the preceding relationships, therefore, we have:

$$E_{11} = \frac{E_L}{1 - \nu_{LT}\nu_{TL}}$$

$$E_{22} = \frac{E_T}{1 - \nu_{LT}\nu_{TL}}$$
$$E_{12} = \frac{\nu_{LT}E_T}{1 - \nu_{LT}\nu_{TL}} = \frac{\nu_{TL}E_L}{1 - \nu_{LT}\nu_{TL}}$$
$$E_{33} = G_{LT}$$

Recall that the two major Poisson coefficients *(major* and *minor)* are in practice related to Young's moduli by the relationship:

$$\frac{\nu_{LT}}{\nu_{TL}} = \frac{E_L}{E_T}$$

so that, as already noted, of the 5 elastic constants only 4 are independent. At this point the mechanical behavior of the lamina has been completely described in terms of the physical quantities of interest.

PREVIEW

Finally, by matching these special-case stress–strain expressions with the corresponding rows and columns of the generalized Hooke's law, we can directly identify how each of the four engineering constants, E_L, E_T, L_T, and ν_{LT}, enters into the stiffness matrix. In practice, one substitutes the uniaxial longitudinal and transverse tension formulas, as well as the pure-shear relationship, into the general constitutive equations and compares coefficient by coefficient. This direct comparison yields exact algebraic expressions that relate each individual entry of the stiffness tensor to one of the four measurable material properties. In this way, the abstract matrix elements acquire clear physical significance, closing the gap between the formal tensor notation of orthotropic elasticity and the familiar engineering constants used in laminate design.

One has:

$$S_{11} = \frac{1}{E_L}$$
$$S_{22} = \frac{1}{E_T}$$
$$S_{12} = -\frac{\nu_{LT}}{E_L} = -\frac{\nu_{TL}}{E_T}$$
$$S_{33} = \frac{1}{G_{LT}}$$

Ultimately, in the plane case the stiffness matrix and the compliance matrix take the forms:

$$[E] = \begin{bmatrix} \frac{E_L}{1-\nu_{TL}\nu_{LT}} & \frac{\nu_{LT}E_T}{1-\nu_{TL}\nu_{LT}} & 0 \\ \frac{\nu_{LT}E_T}{1-\nu_{TL}\nu_{LT}} & \frac{E_T}{1-\nu_{TL}\nu_{LT}} & 0 \\ 0 & 0 & G_{LT} \end{bmatrix}; \quad [S]$$
$$= \begin{bmatrix} \frac{1}{E_L} & -\frac{\nu_{LT}}{E_L} & 0 \\ -\frac{\nu_{LT}}{E_L} & \frac{1}{ET} & 0 \\ 0 & 0 & \frac{1}{G_{LT}} \end{bmatrix}$$

PREVIEW

Because an orthotropic lamina with unidirectional fibers is also isotropic within its transverse plane, its full three-dimensional elastic behavior can be described with just five independent constants, rather than the nine required for a general orthotropic material. If we denote by T′ the axis perpendicular to the fiber–matrix plane (the “thickness” direction), then the transverse Young’s modulus and in-plane shear and Poisson’s ratios are the same in both transverse directions:

$$E_{T,} = E_T; \quad G_{LT,} = G_{LT}; \quad \nu_{LT,} = \nu_{LT};$$

The only additional constant needed is $\nu_{TT'}$, the Poisson's ratio that couples the two transverse axes. Once $\nu_{TT'}$ is known, the remaining transverse shear modulus follows from the same isotropic relation used in metals and polymers:

$$G_{TT'} = \frac{E_T}{2(1 + \nu_{TT'})}$$

Thus, to characterize a transversely isotropic lamina in three-dimensional stress states, we need five parameters: E_L, E_T, G_{LT}, ν_{LT}, and $\nu_{TT'}$. Finally, when loads are applied in arbitrary directions within the plane of the lamina, one must rotate these material constants by the appropriate transformation matrix to capture the correct anisotropic response.

PREVIEW


Elastic matrix for lamina loaded along arbitrary direction

When plies are oriented at some angle other than their principal material axes, the relationship between stress and strain must be expressed in a rotated coordinate system. In a general Cartesian frame (one that does not coincide with the fiber and transverse directions) the stiffness and compliance matrices lose their simple, sparse form and become fully populated. In other words, every stress component can induce every strain component, and vice versa.

However, from a geometric standpoint, the material still "prefers" its principal axes, those aligned with the fiber direction and the transverse directions. To analyze the response in an arbitrary orientation, we employ tensor-rotation rules derived from continuum mechanics. Specifically, we use transformation matrices to rotate the stress and strain tensors

by the ply angle θ. By applying these rotations to the known stiffness (or compliance) matrix in the principal system, we obtain the full stiffness (or compliance) matrix in the new, arbitrarily oriented coordinate system.


In practice, this process involves pre- and post-multiplying the principal stiffness matrix by direction-cosine matrices that encapsulate the angle θ. The result is a set of transformed elastic constants that correctly predict how the lamina will deform and carry load when its fibers lie at any chosen in-plane angle. This approach is the cornerstone of Classical Laminate Theory and enables the design of multi-angled layups that tailor stiffness, strength, and thermal expansion to meet complex structural requirements.



PREVIEW

Figure 142 - Rotation of the reference system

Because these transformation rules spring only from balance and geometric considerations, they hold for any linear elastic material. In essence, when you have the normal and shear


Dry Fibers: Density vs Specific Modulus
Specific Modulus E/ρ [GPa·cm³/g]
Density [g/cm
Carbon
Carbon
Carbon
Aramid
Flax
Glass
Basalt
PREVIEW
Fiber Type
Carbon
Aramid
Basalt
Glass
Flax