

Made in the Kingdom of Bahrain

Omega Unicryl Pure

Area: Internal Walls and Ceilings

Substrate: Cement Plaster, Concrete, Block Work, Gypsum Board, etc.



Surface Preparation

- 1. Ensure that the plastered surface is cured at least 21-30 days;
- 2. Remove all loose particles, sharp edges, nibs, etc., by abrading the surface with sand paper, scrapper, rubbing stone, etc.;
- 3. Ensure that surfaces to be painted must be clean, dry, and free of dirt, grease, oil, soap, wax, scaling paint, water soluble materials, and mildew;
- 4. Make sure the moisture content is below 12% and well-ventilated before painting

Recommended Paint System - Silk Finish							
Coat Stage	Product Code	Product Name	VOC (g/L)	DFT (µm)	No. Of Coats	Drying Time / Over coating Interval*	Application Tool
Primer	2010	Omega Unicryl Primer (Wb)	25	30	1	1 h	Roller, Brush, Spray
Prep	6004	Omega Powder Filler	0	-	1	1 h	Stainless Steel Trowel
Prep	6000	Omega Unicryl Putty	5	100	1	2 h	Stainless Steel Trowel, Filling Knife, Spatula
Primer	2010	Omega Unicryl Primer (Wb)	25	30	1	1 h	Roller, Brush, Spray
Top Coat	4006	Omega Unicryl Pure	25	30	2	2 h	Roller, Brush, Spray

Refer to Omega Paints Technical Data Sheets for more information

^{*}High humidity and cooler temperatures will result in longer dry, re-coat and service time.