



Omega Unicryl Weatherproof

Area: External Walls and Parapets

Substrate: Cement Plaster, Concrete, Block Work, Gypsum Board, etc.

Surface Preparation

1. Ensure that the plastered surface is cured at least 21-30 days;
2. Remove all loose particles, sharp edges, nibs, etc., by abrading the surface with sand paper, scrapper, rubbing stone, etc.;
3. Ensure that surfaces to be painted must be clean, dry, and free of dirt, grease, oil, soap, wax, scaling paint, water soluble materials, and mildew;
4. Make sure the moisture content is below 12% and well-ventilated before painting
5. An additional coat of Signature Premier 2010 WB Primer is recommended on top of Omega 6004 Powder Filler, depending on surface condition and leveling requirements.

Recommended Paint System - Any Finish

Coat Stage	Product Code	Product Name	VOC (g/L)	DFT (µm)	No. Of Coats	Drying Time / Over coating Interval*	Application Tool
Primer	2010	Omega Unicryl Primer (Wb)	25	30	1	1 h	Roller, Brush, Spray
Top Coat		Omega Unicryl Weatherproof	0-50	55	2	2 h	Roller, Brush, Spray

Refer to Omega Paints Technical Data Sheets for more information

**High humidity and cooler temperatures will result in longer dry, re-coat and service time.*