

# **IMPORTANT** **PLEASE READ**

Before you start – Your oven slab needs to be placed on a fully supported non-flammable base, by this we mean a solid surface. You can place an ordinary concrete slab, metal plate, marble or similar underneath the oven slab, this will support the weight of your oven bearing down on the slab provided and prevent it from cracking due to the expansion and contraction due to hot and cold spots.

Although hairline curing cracks are quite normal, your oven slab has been reinforced with steel rod to prevent it from breaking. Please position your oven a suitable distance away from shreds/ wooden structures and fences.

Once you have arranged your base, place the dome oven on top of the oven slab, there is no need to seal around the oven. With the fire bricks provided, place 3 in a row just inside and then place a row of 4 or more behind. The remaining 3 need to be placed on their edge lengthways with one at the very back and one either side

## **CURING YOUR OVEN BEFORE USING FOR THE FIRST TIME**

### **WOOD ONLY!!**

**USING SMALL PIECES OF DRY KINDLING, START A FIRE INSIDE THE ENTRANCE AND ALLOW IT TO GO OUT. THIS ERADICATES ANY MOISTURE. THIS SHOULD ALSO BE DONE AFTER PERIODS OF NON USE.**