

# UC Lab Biosolid Kit Examples

## 503 Complete Biosolid



## 503 Biosolid Complete with Pathogens



## 503 Biosolid Complete with Pathogens and PFAS



**PFAS for Wastestream or Biosolid samples**

**PFAS for Biosolid samples ONLY**

**503 Complete:** 1,000 mL unpreserved bottle  
**Mercury:** 250 mL unpreserved bottle  
\*\*Both bottles must be filled.\*\*

**2 bottles total**

**Both of the '503 Biosolid Kit' bottles**  
**Pathogens:** Seven 150 mL sterile bottles with sodium thiosulfate

**9 bottles total**

**All of the '503 Biosolid with Pathogen Kit' bottles**  
**1 of the above PFAS bottles**

PFAS bottles are certified clean by the contract lab.

**10 bottles total**

**ALL BOTTLES MUST BE FILLED FOR REQUESTED TESTING**

Please make sure all labels and Chain of Custodies are correctly filled out with Client information (Client, Date, Time, and Analytes).