

Measuring your head for a custom fitted hat

The following steps will help to ensure your custom wooden hat is a perfect fit.

1. Buy or borrow a curvex (flexible) ruler.



2. Place the curvex ruler around the head at the exact place where the hat will be positioned when worn. Hold the curvex ruler with two fingers on each side or the front and back of the head. Wrap the ruler around the head approximately 1/8 to 1/4 inch above the ears.



3. Push the ruler against the head so that there are no spaces between the ruler and the head. (the ruler will overlap at the ends).



4. While wearing the ruler, pinch the overlapping ends of the curvex ruler together so that the size does not change while removing it from your head. Make certain not to change the size or the shape of the conformed ruler when removing it from your head as this will dramatically affect the size and shape of the final product.



5. Place the ruler on a piece of paper making certain not to change the size or shape of the conformed ruler and trace the inside of the ruler's size/shape on a piece of paper to make a pattern of the head. BE SURE TO MARK WHICH END OF THIS DRAWING IS THE FRONT OF YOUR HEAD. Repeat the steps 2-5 two more times, (using the same piece of paper, overlapping the tracings) to verify that the measurement remains the same each time.



6. Mail this drawing to us at:
I Just Make Stuff
PO Box 648
Geneva, OH 44041