

The First-Time Homeowner's Interior Painting Prep & Materials Master Guide



This guide was authored by **Russell Moshay Youngblood**, a licensed residential general contractor and owner of **True North Asset Management LLC**, based in Bel Air, Maryland. With extensive experience in property maintenance and renovation, Russell provides professional-grade insights to help homeowners achieve expert results on their own DIY projects.

Step 1 The Supply & Budget Planner

Success in painting begins before you open a single can of paint. Follow this guide to ensure you purchase exactly what you need, minimizing waste and mid-project trips to the hardware store



Item Category	Essential Tools & Supplies	Professional Usage Tip
Measurement	Tape Measure, Pencil/Notepad, Calculator	Always calculate wall area (Length x Height) minus doors/windows.
Surface Repair	Spackle, Sanding sponges (120-150 grit), Putty knife	Sand patches smooth before priming to prevent "flashing."
Protection	Painter's Tape (Blue or Green), Canvas Drop Cloths	Canvas holds paint splatters; plastic sheets are slippery.
Application	High-quality Angled Sash Brush, Roller Frame, Roller Covers	Use 3/8" nap rollers for standard smooth drywall.

Step 2: Room-by-Room Surface Check

Before applying paint, you must understand the surface you are working with.

- A. **The Latex vs. Oil Test:** Rub a cotton ball dampened with denatured alcohol over an inconspicuous area of your current trim or wall. If paint comes off on the cotton, it is latex. If not, it is likely oil-based and requires a high-adhesion bonding primer.
- B. **Moisture Check:** Inspect corners for mildew. Clean with a 1:3 bleach-to-water solution if necessary, and ensure the wall is completely dry.
- C. **Texture Assessment:** Note areas where drywall seams or previous patches might "flash" (appear differently through the final coat). This requires extra primer coverage.



Step 3: The 10-Step Painting Prep Checklist

1. **Clear the Room:** Move all furniture to the center; remove small items and curtains.
2. **Remove Hardware:** Unscrew light switch plates, outlet covers, and wall hardware. Store in labeled bags.
3. **Dusting:** Vacuum ceiling corners and baseboards to remove cobwebs and dust.
4. **Wall Cleaning:** Wash walls with TSP or a mild degreaser to remove oils/grime.
5. **Patching:** Fill holes with spackle; allow to dry completely.
6. **Sanding:** Sand all patches flush; lightly scuff-sand the entire wall surface.
7. **Cleaning (Again):** Wipe away all sanding dust with a damp, clean cloth or tack cloth.
8. **Masking:** Carefully apply painter's tape to baseboards, window casings, and crown molding.
9. **Pressing Tape:** Run a putty knife over the tape edges to seal them tight against the trim.
10. **Final Sweep:** Lay canvas drop cloths over your clean floor.



Step 4: Troubleshooting & Quick Fixes

Disaster	Immediate Fix
Tape pulled off original paint	Apply spackle, sand flush, spot-prime, and re-paint.
Drywall patches "flashing"	Apply an additional coat of high-quality primer to the patched area.
Paint bleeding under tape	Wipe away immediately with a damp rag, or touch up with the original trim color once dry.

Ready to Transform Your Space?

Tackling a major home improvement project can feel overwhelming, but you don't have to do it alone. If you find yourself in need of professional assistance, expert craftsmanship, or have questions about your next residential renovation, contact True North Asset Management LLC today!

Website: truenortham.com Maryland Home Improvement Commission

(HMIC) **License:** #05-169183