



All on X case Stages

Stage 0: Pre-Op records

- Absolutely CRUCIAL for accurate immediate load
- Can be done digitally with IO scans or also with impressions
- Proposed VDO for the case must be determined at this stage
- Records sent to lab technician for Pre-Op plan

Stage 0 Records must:

- Determine the VDO
- Determine the proposed implant positions
- Determine how the immediate load appliance will be fabricated and converted during surgery
- Determine the amount of bone reduction needed
- Determine the type of Prosthesis to be restored
- Determine the ideal smile for the patient

8 Items

1. Radiographs
2. Photos
3. VDO
4. IO scans (upper, lower, bite)
5. Facial Scans
6. Type of Prosthetic Planned (FP1, FP2, FP3)
7. Alignment Strategy
8. Lab Slip

If your stage 0 records are off, your case will be off

Stage 1

Who is providing parts & type of temp for surgery

