



FIRED ^{UP} KILNS

and pottery supplies

Midfire Powder Glaze Instructions

Mixing up 1 kg of glaze from powder for dipping, pouring, or spraying:

- Wearing a suitable mask, sprinkle the glaze powder into a suitable container of water.
- Stir thoroughly.
- Leave to settle overnight and skim off surplus water.
- Stir, sieve through an 80 mesh or finer sieve, then add water if necessary to achieve the desired consistency a bit thicker than Full Cream Milk.

(Note: When adding water: add very cautiously, stirring well between additions)

Using the mixed glaze:

Liquid glazes can settle out over time. They sometimes set hard at the bottom of the container, making them difficult to re-mix.

To correct this defect, a flocculent or anti-set solution should be added a little at a time.

Epsom salts are a good flocculating agent. Adding 1% of a saturated Epsom Salt solution to your glaze mix with thorough stirring will re-suspend your glaze mix.

Glazes may also settle during use and consequently demand thorough stirring or agitation during the dipping / pouring / spraying session.