

HS Dominie T1 Late Model Nose Conversion

AIR.
AC-040

Instructions: Cut the kit nose as shown on the drawings, using the panel line immediately forward of the cockpit as a guide. Make the cut in front of this line towards the nose.

Test fit the nose with the forward cockpit bulkhead, Part 8, in place. It may be necessary to trim and/or sand down the flat rear face of the resin plug to obtain a good fit.



Drawings
Gary Madgwick 2018

1:72
Scale