



Installation Instructions

4-Post Canopy Standard Duty Frame

Step 1: Remove boat from lift.

Step 2: Set scaffold system to reach entirety of canopy being installed.

Step 3: Lay out slide tracks and/or lower legs evenly spaced along length of top beams and thru-bolt in place. Never exceed 8' spacing. If using slide tracks, determine proper leg width positioning before tightening down.

Step 4: Insert upper legs into the lower legs, adjust for level height, and thru-bolt.

Step 5: Place side rail into saddles of upper legs and affix with thru-bolts and backing plates.

Step 6: Place bows over receiver pins along the side rails.

Step 7: Place center spans over receiver pins in between bows.

Step 8: Use self-tappers to secure all bows and center spans.

Step 9: Affix rail kicker brackets using thru-bolts/backing plates. Affix pile kicker brackets using lag bolts. Measure for kickers, cut to length, and affix with thru-bolts.

Step 10: Lay out tarp on frame, center, and affix with straps.

Step 11: Remove scaffold system and replace boat.