Installation instructions:



V-11RainDiverter

Great Alternative to Gutters

Protects doorways and gardens from rain. Sleek and hardworking - the V-11 Rain Diverter is a great alternative to traditional gutters.

- 1. Carefully lift the tabs of the roofing shingles where you are going to install the V-11 rain diverter. (The V-11 rain diverter is designed to be installed across one course of shingles.)
- 2. Place the V-11 rain diverter under the tabs of the roofing shingles.
- 3. Tilt the V-11 rain diverter in the direction that you want the water to flow.
- 4. Nail the V-11 rain diverter down with roofing nails.
- 5. Place roofing cement or some other acceptable sealant down under the roofing shingle tabs to secure them.

www.v11raindiverter.com