



STEP 1
UNZIP BAG.
CAREFULLY TURN BACK RIGHT SIDE OUT.



STEP 2
FILL BAG, HEAVY ITEMS ON BOTTOM.
DO NOT TAMPER WITH PARACHUTE.



STEP 3
FOR EXTRA PROTECTION, USE A SECOND
BAG TO CONTAIN CARGO. PLACE PADDING
BETWEEN THE INNER AND OUTER BAGS.



STEP 4
ZIP BAG CLOSED, SECURE FLAP SNAPS.
PARACHUTE AND HARNESS SHOULD STILL
BE WITHIN THE VELCRO PROTECTOR.



STEP 5
WEIGH BAG. IT IS READY FOR AIRDROP.



NDRAB MUST WEIGH:
30 POUNDS MINIMUM
103 POUNDS MAXIMUM