



Problem

- Roofs don't leak until it rains.
- Keeping water away from the repair area is key to a successful service call.
- With labor rates rising, do you want two trucks at a service call?

Solution

- Forms a watertight ridge instantly
- Controls water at the source
- Creates a safe, dry workspace
- Reduces interior damage
- Professional, confident service
- Saves Time and Money

Step	Asset	Task
1		Clear water towards roof drain. Flash-Dam works best in 1/2" deep water.
2		Create the Dam: Sprinkle approximately 1oz of Flash-Dam per 3 linear feet of dam needed.
3		Once the perimeter is established with Flash-Dam, at least 12" away from the work area, Clean area to be addressed.
4		Complete your repair as needed
5		Sweep the used Flash-Dam using a broom and small dust pan. Empty in a plastic bag and dispose of properly, in the garbage.