

PDR 1000 Instructions

- 1) Install 9 volt battery into bottom of unit
 - 2) Go to a clean environment prior to turning on machine
 - 3) To turn on machine, Press **ON/OFF** button to turn on/off machine
 - 4) Start ZERO by clicking **ENTER**
 - 5) Zeroing takes 1 to 2 minutes, **DO NOT TOUCH** any buttons
 - 6) Once its completed, screen should say: "Calibration OK, click **NEXT**"
 - 7) START RUN – Click **ENTER**
 - 8) Your PDR 1000 is now up and running!
-

Viper II Factors Look Solutions Fog Fluids

Reg x 1.46 Quick X 2.02