

# PDR 1000 Instructions

- 1) Install 9 volt battery into bottom of unit
- 2) Go to a clean environment prior to turning on machine
- 3) To turn on machine, Press **ON/OFF** button to turn on/off machine
- 4) Start ZERO by clicking **ENTER**
- 5) Zeroing takes 1 to 2 minutes, **DO NOT TOUCH** any buttons
- 6) Once its completed, screen should say: "Calibration OK, click **NEXT**"
- 7) START RUN – Click **ENTER**
- 8) Your PDR 1000 is now up and running!