

Your cards will come programed to the lock,
If you are going to use the bluetooth option
you will need to press reset button on the lock first,
then follow bluetooth setup instructions below.
Once Bluetooth has been setup, you will need to
reprogram your cards.

BLUETOOTH INSTRUCTIONS

Step 1 - Install app from app store

(Kerong Cabinet Lock Admin - it will be BLACK)

Step 2- Open App, 

Step 3-Tap the scan bar icon in top left corner
and scan code on the back of lock.

Step 4- Enter paired password/pin confirm

Step 5- Enter your area code and phone number and confirm.

Step 6- Enter management verification code 000000 confirm

INSTRUCTIONS TO PROGRAM CARDS

First set the manager card by pushing button 1 on back of lock
for 2 seconds, then place manager card over the lock- you should
hear one long beep, this indicates manager card is now set.

Wait 30 seconds and swipe manager card, you should hear a long beep
immediately swipe user cards (you should hear a long beep
after each card indicating it was successful.) Wait 30 seconds and verify
the user card is working with the lock. **DO NOT CLOSE THE ITEM
OR HANG IT UNTIL YOU HAVE VERIFIED THE CARDS OR
BLUETOOTH ARE WORKING.**