

1. Start by laying all the pcs out on a flat surface.

- 2. Lay the two logs parallel to each other and space them approximately 22 inches apart. The ends of the logs and Edges of the boards are marked to tell you which is the Left or Right and Top or Bottom. Fig. 1
- 3. Find the long board marked "Bottom" and orient it as shown in Fig. 2.Insert two 2" screws and tighten. Be sure to line up the pre-drilled holes. Fig. 2
- 4. Find the small board marked "Bottom" and using three 1.625" screws fasten to the top shelf as shown in Fig. 3 & 4, being sure to line up the pre-drilled holes.
- 5. Repeat steps 3-5 for the boards marked "Top"
- 6. Insert the pegs into the holes on the front of the logs and fasten from the back using a 2" screw. Fig. 5 & 6. You may need to loosen the screws holding the logs and turn them to orient the pegs in the correct position and then retighten the screws.
- 7. Enjoy.

Cedar Log Gun Rack assembly instructions





