

PIERTECH SYSTEMS

(866) 536-5007 | SALES@PIERTECH.COM

TRU-LIFT BRACKET

WWW.PIERTECH.COM

- **PATENTED** • **EASY TO INSTALL** • **LIGHTWEIGHT** •
- **VIRTUALLY MOMENT FREE** • **NO ANCHOR BOLTS REQUIRED** •

INSTALLATION PROCESS:

- INSTALL HELICAL PIER AND CUT TO THE PROPER HEIGHT
- ROTATE BRACKET INTO POSITION TO PLACE BRACKET SEAT UNDER FOOTING
- INSTALL SLIDER BLOCK AND THREADED RODS
- PLACE JACKING BLOCK IN POSITION AND APPLY LOAD
- COMPLETE BY CUTTING THE THREADED RODS TO THE APPROPRIATE HEIGHT



Per Tech
SYSTEMS®

ADDITIONAL BRACKETS



- NEW CONSTRUCTION BRACKET
- BOARDWALK SADDLE BRACKET
- PORCH BRACKET
- SLAB BRACKET
- LIGHT DUTY BRACKET
- DECK BRACKET
- ADJUSTABLE OIL FIELD BRACKET



DRIVEN BY INNOVATION

(866) 536-5007 | SALES@PIERTECH.COM