

Epoxy Primer

2.1 VOC

Product Numbers:

| | |
|---------------------------|--------------------------|
| 6600-1 White (gallon) | 6600-4 White (quart) |
| 6610-1 Gray (gallon) | 6610-4 Gray (quart) |
| 6620-1 Black (gallon) | 6620-4 Black (quart) |
| 6630-1 Red Oxide (gallon) | 6630-4 Red Oxide (quart) |
| 6700-1 Activator (gallon) | 6700-4 Activator (quart) |

SPI Epoxy Primer is one of the finest available and great for use on any type of metal if properly sanded and cleaned. **This epoxy eliminates the need for an acid-etch primer.** Use this epoxy on bare fiberglass or SMC before applying body fillers or 2k primers for best long-term results.

Mixing: 1:1

Mix 1 part Epoxy Primer to 1 part Epoxy Activator

30 minutes of induction is recommended

When you first open the epoxy primer, it is VERY important to make sure that all settling on the bottom of the can is mixed up very well with a paint stick. If not mixed properly, you can destroy the epoxy. Paint shakers **DO NOT** perform well with settled epoxy so always use a paint stick.

We strongly recommend when you activate the epoxy to stir and mix very well before letting it sit/induce for 30 minutes. Stir once again before spraying and the longer you wait between spraying your coats of epoxy the better.

Pot Life:

72-120 hours depending on humidity and temperature (stored in a sealed container)

Prepping the Surface:

When prepping for epoxy always sand with 80 grit DA paper. Metal must be clean of all rust, oils and any films. **Never** clean metal with lacquer thinner, acetone or reducers of any kind.

Clean surface with SPI 700-1 Waterborne Wax and Grease Remover then clean with SPI 710-1 Solvent based Wax and Grease Remover and let sit for 45-60 minutes before applying epoxy.

If you have any questions on how to prep any type of substrate please call our tech line before beginning.

Body Fillers:

On any restoration, it's **always best to apply the body filler over the epoxy** rather than applying filler over bare metal for best adhesion and corrosion protection. After applying two coats of epoxy wait overnight before applying the body filler. The epoxy does not need to be sanded before applying the body filler for up to 7 days as long as it doesn't go outside.

If time allows, it's always best to apply filler over the epoxy after it has set for 24-48 hours.

If you choose to do the filler work over bare metal, the epoxy can be sprayed over the sanded body filler.

Spraying:

Spray two wet coats for normal applications. For special projects such as restorations, spray one coat and let it flash 30 minutes or longer at 70 degrees or higher. Then spray a second coat for maximum corrosion protection. For frames we recommend three coats to make sure you don't have any thin spots as frames tend to be tougher to spray. **You do not need to top-coat our epoxy on frames, wheel wells, firewalls or suspension components.**

For older corvettes such as early 70's and older, 3 wet coats of epoxy will perform best. Any cleaning of the raw glass should be allowed to sit 24 hours or longer before applying the epoxy. Apply one wet coat of epoxy, let it sit 1-4 hours then spray a second coat. If a third coat is desired again wait 1-4 hours before applying the next coat.

This epoxy does not need to be sanded if it's primed over within 7 days. Always prime over the epoxy within 7 days. After 7 days, the epoxy should be sanded with 180 grit and recoated with epoxy for best adhesion.

Polyester Primers:

When using a polyester type primer always let the epoxy sit for at least 48 hours.

Wet and Dry Sanding:

If you need to sand a large area of epoxy, the epoxy will dry sand best after 12-16 hours. Wet sanding with moderate pressure can be done after about 4 hours depending on the amount of epoxy applied, air temperature and substrate temperatures.

To use as a Paint Sealer:

To use this epoxy as a paint sealer, reduce it 5-50% with the proper temperature range urethane reducer (this is very important) and spray with your base/clear gun. Spray one wet coat **ONLY**, let it sit 2 hours then apply paint. For sealing of a potential problem paint job, apply two coats of epoxy with proper flash times between coats and let it sit overnight before painting.

Remember, reducing epoxy speeds up the cure time so when mixed as a sealer the best application of base is within 2-18 hours (no sanding is required within this time frame).

Cold Weather:

In cold shop conditions this primer can and will go dormant. Keep heat on the car for 24 hours after spraying with an absolute minimum metal temperature of 65 degrees. Also, when it's cold it will help to mix the primer and let it induce 60 minutes before spraying. Application of any epoxy in cold weather can destroy a paint job.

Bottom line is if the car metal cannot be kept at 65 degrees or higher as well as the shop temperature for the next 24 hours after spraying, **DO NOT** spray our epoxy as you may end up having to redo all your hard work.

Also, temperature of the epoxy in the can is just as important so store the epoxy in a warm place for at least 24 hours before spraying.

For \$20 you can buy a laser temperature gun to take readings of the can and the car panels and this will save you from guessing.

Once again if you have any questions regarding the application of SPI Epoxy Primer in cold weather please call us first. Metal temperature when you spray epoxy is critical and must be at least 65 degrees as well as the contents of the epoxy and activator cans!

Neutralizing Skyco Ospho:

Ospho is the only rust treatment we recommend IF needed under epoxy primer.

Apply Ospho as needed and leave it on as long as you like.

When you are ready to neutralize the dry Ospho, apply one more coat of Ospho over the area to be neutralized and let it set for 5 minutes.

Using a clean towel and water, wash off the wet Ospho like you are washing a car then dry with a clean towel.

A dry acid film can't be neutralized or sanded off.

Neutralizing a soda blasted vehicle:

Thoroughly wash every square inch of the vehicle using Dawn Original Formula, Purple Power Degreaser, or Simple Green mixed with water and a clean towel. Wash every square inch of the vehicle like you are washing a car. Rinse off with clean water then dry.

Media blasted vehicles:

Unlike sandblasting, media blasting doesn't leave a coarse enough surface for the epoxy so sand the vehicle with 80 grit on a DA sander. All we need is a decent scratch, so this process shouldn't take more than 60 minutes to do the entire exterior of a typical vehicle.

Precautions:

NEVER use SPI Epoxy Primer over acid etch/wash primers or rust converters. It will not work and we strongly suggest if you want to use a rust converter that you use the rust converters paint system instead of SPI.

Acid treatments should not be used unless you know the proper way to neutralize them. Again, call us to be safe as acid films can cause an adhesion loss.

We only recommend using Ospho's acid treatment if you even need one.

If not handled properly these issues can destroy a paint job and will result in an expensive mistake.

For bare metal or aluminum DO NOT use any other cleaner except for SPI's 700-1 Waterborne Wax and Grease Remover.