

CUT OR FOLD ALONG THIS LINE

↑ SEAT BASE ↑
DRIVER SIDE

2.38"

4.63"

Ø.5"

CUT OUT THE CENTER HOLE ON TEMPLATE
MARK DRILLING LOCATION ON FLOOR



DRILL TEMPLATE

2007-2018 MERCEDES BENZ SPRINTER 3500 CHASSIS CAB FRONT BOLT-ON APPLICATION

ATTENTION:

VERIFY PRINTED TEMPLATE MEASUREMENTS ARE TO SCALE BEFORE USING FOR INTALLATION
(USE 'ACTUAL SIZE' PRINT SETTING)

4.5"

- STEP 1**
REMOVE TOP PLASTIC TRIM PIECE OVER SIDE STEP
(THREE TORX SCREWS PER SIDE)
- STEP 2**
REMOVE OR PULL OUT OF PLACE THE RUBBER FLOOR MATERIAL
- STEP 3**
USE TEMPLATE TO DRILL TWO HOLES PER SIDE WITH 1/2" DRILL BIT
- DO NOT RE-INSTALL FLOOR MATERIAL
UNTIL INSTALLATION IS FINISHED

↓ SIDE STEP PLASTIC TRIM ↓

CUT OR FOLD ALONG THIS LINE

6.88"

2.38"

4.63"

Ø.5"

CUT OUT THE CENTER HOLE ON TEMPLATE
MARK DRILLING LOCATIONS ON FLOOR

PASSENGER SIDE
↓ SEAT BASE ↓

CUT OR FOLD ALONG THIS LINE