

2024+ Mercedes Benz Sprinter 3500 Driver Side Drill Template

(Check template measurements before drilling)

CUT AT LINE

DRIVER

- Cut out template
- Position template in driver side step well
- Mark cent of the 4 holes on vertical step wall
- Drill holes using a 9/16" drill bit

Ø.563"

2.5"

7.5"

5"

EDGE TO FLOOR OR
▽ BOTTOM OF STEP WELL ▽

EDGE TO REAR CORNER
▽ OF VERTICAL STEP WALL ▽

CUT AT LINE

CUT AT LINE

CUT AT LINE

