

RV Shower Corner Storage Bar

Thank you for your purchase of the Shower Corner Storage Bar! If you have any questions or issues with the bar, please message us on Etsy. We would be happy to help!

Installation instructions:

1. Determine where you will mount the storage bar.
 - a. We recommend putting your toiletry item in the corner shelf before installing, so you can decide on a good height to install the bar. If you install the bar too high or too low, the toiletry item(s) may slip out during transit.
 - b. We have found that putting the bar 3-4 inches from the base of the shelf is a good height.
 - c. Once you have determined where the bar will go, expand the bar and use a pencil or marker to mark where to drill your holes. Using a level and tape measure may help with getting the bar straight.
2. Drill the Holes.
 - a. Remove the bar from the wall and use the provided drill bit to pre-drill holes where you marked.
3. Mount the bar.
 - a. We recommend putting a dab of caulk on the ends of the tubes to seal up the holes made.
 - b. Use the provided screws to fasten the bar to the wall. **DO NOT OVERTIGHTEN THE SCREWS.** They only need to be snugged up. If you overtighten the screws, you could break the bar.
4. If you are satisfied with the product, or have questions, please contact us on Etsy.

Follow us on social media:

Facebook: <https://www.facebook.com/GrantedEngineering>

Instagram: <https://www.instagram.com/grantedengineering/>

TikTok: @grantedengineering

We have several other helpful RV products available www.grantedengineering.com



RV Water Heater Drain Funnel



RV Table Leg Mounts