

M18V3

SETUP

INSTALL STARLINK MINI

- Squeeze Lid Keeper to the left till holes line up
- Install 2 Gold Lynch Pins (or other 1/4 diameter rod)
- Slide Starlink Mini into lid. Power cord installs from LEFT
- Hold Starlink Keeper while slowly removing lynch pins
- Insert Starlink Power Cord

INSTALL BATTERY(s)

- Remove Plastic Safety from Power Tray
 - Slide a Milwaukee Battery into slot until there is a 'Click'.
- *MAX BATTERY SIZE = M18 FORGE XC8.0*

OPERATION

TURN ON BATTERY

- Turn 'ON' battery switch (inside case) of the battery slot you want use. If multiple switches are 'ON' - it the load will evenly draw from the chosen batteries.

SET CASE OUTSIDE

- Set Kodiak Case outside with the lid facing the sky.

PUSH ON STARLINK POWER

- Power Button is on outside of the case.
- The voltage should display if power is ON.
- Wait approximately 1 minute and your Starlink WIFI

PUSH OFF STARLINK POWER

- When finished using, just push off lighted power button

USING EXTERNAL POWER

The Kodiak Case automatically senses external power and will prioritize over battery.

- On the outside of the case next to the power button is POWER INPUT PORT compatible with Starlink provided cord. The other end of the cord can use either the starlink provided AC adapter or Kodiak Case provided DC adapter.

CHARGING

- Plug into external Power
- Turn Charger Switch (inside case) to 'ON'
- Ensure Battery Switches are 'ON'

WIFI:

PASSWORD: