

NOVACROWN

Going Where Crown Moulding Has Never Gone Before

TOOLKIT

For installations at drywall stage we suggest you will need:

1. Fine-tooth 10 inch compound mitre saw
2. Taping compound
3. Drywall mud applicator such as a bazooka
4. Latex caulking
5. Caulking gun
6. Cloths
7. Putty scraper
8. Tape measure
9. Pen & paper to draw & label perimeter map & label measurements on back of mouldings
10. Ladder(s)
11. Fine grained soft sanding sponge

For installations post construction we suggest you will need:

1. Fine-tooth 10 inch compound mitre saw
2. Latex caulking
3. Caulking gun
4. Cloths
5. Putty scraper
6. Tape measure
7. Pen & paper to draw & label perimeter map & label measurements on back of mouldings
8. Ladder(s)
9. Fine grained soft sanding sponge

Check out our installation video for more information