

# NOVACROWN

*Going Where Crown Moulding Has Never Gone Before*

## Installation Guide

1. Draw map of perimeter lengths then add your measurements to the map.
2. Pre-cut NovaCrown (we use a 10" compound mitre saw) according to perimeter lengths and label measurements on backside.
3. Use Alex Plus to adhere NovaCrown to wall and ceiling. At drywall stage adhere with taping compound simultaneously with corner bead and tape. Apply bead to inner edge of contact shoulder on backside to prevent squeeze-out.
4. Apply Alex Plus or Kwik Seal to seams and joints. Where walls exceed moulding lengths we recommend butt-jointing.
5. After installation use Alex Plus or Kwik Seal to caulk gap between ceiling and wall.