



Thru-Wall Flashing System

Flash Trac, Inc.

"NO FLASHING BEFORE IT'S TIME"

TECHNICAL DATA SHEET

www.Flashtracsystems.com

Welcome to the Flash Trac™ System.

The Flash Trac™ System is an extruded plastic through wall flashing receiver. Flash Trac™ simply attaches to the exterior sheathing. It is designed to be installed before any spray foam insulation is installed. This enables the flashing to be installed after spray foaming occurs preventing distortion and contamination. The Flash Trac™ System works with most flashing membrane materials.

Flash Trac™ is available for most standard thicknesses of spray foam insulation; i.e. 2, 3, or 4 inches. It is available in 5 and 10 foot sections and can be field cut for specific lengths.

LIMITATIONS

There are no known limitations for this product when it is used in the manner for which it was designed.

MATERIALS AND COMPOSITION

The Flash Trac™ System is manufactured from Acrylonitrile-Butadiene-Styrene (ABS) material. ABS has an outstanding impact resistance and performs well in all temperatures.

SYSTEM COMPONENTS

The Flash Trac™ System consists of a wall bracket (receiver) and a retaining rod.

SIZES

The Flash Trac™ System is available in standard spray application thicknesses of 2, 3, or 4 inches.

COLORS

The Flash Trac™ System is available in White.

CHEMICAL RESISTANCE

Not affected by high alkaline environments typical of masonry construction.

STORAGE

The Flash Trac™ System does not have any special environmental storage requirements. Heavy materials should not be stored on top of the boxes containing the Flash Trac™ System.

PREPARATION

The Flash Trac™ System simply attaches to the exterior sheathing. It does not matter whether the surface is wet or dry.

SAFETY

Material Safety Data Sheets (MSDSs) are available for Acrylonitrile-Butadiene-Styrene (ABS) material upon request.

AVAILABILITY AND COST

The Flash Trac™ System can be shipped virtually anywhere.

Contact Wade Holt or for specific pricing or any other questions at (802) 433-1563 ext. 115.

The Flash Trac™ System Installation

The wall bracket/receiver is fastened to the exterior sheathing prior to the installation of spray foam insulation. Once the insulation has been applied and has setup; remove the tape covering the jaw of the bracket. If necessary, clean the area in front of the jaw of the bracket of any overspray of insulation. Wrap the membrane around the retaining rod and insert it into the jaw of the wall bracket.

Patent Pending