



ASSEMBLING THE POWER U

www.manplow.com/assembly-instructions

It is recommended that you build the handle before attaching the blade.

Step 1 **Align the** **Stickers**



Top U

Power U Leg (2)

www.manplow.com/assembly-instructions

1. Connect stickered Power U Leg to stickered side of Top U. The hole to receive the snap button is under the grip. When the stickers are lined up, the Power U Leg will “click” into place.

2. Repeat with the unstickered side.

3. You may need to adjust grips so the ends meet.



42” Snow
Handle Leg

4. Assemble the 42” Snow Handle Legs. Tighten firmly. Do not overtighten.

5. Follow MANPLOW U Handle assembly instructions.

Attaching it to **existing** **equipment?**

If you are attaching the Power U to existing equipment, it is recommended that you loosen the Blade to Handle fasteners and Grab Bar/Throw Bar/Boost Bar fasteners first.

