

PRODUCT:	Rage <sup>®</sup> Ultra		
PART NUMBER:	100125 100127	Gallon 3-Gallon	4 units/case 1 each
DESCRIPTION:	<b>Rage<sup>®</sup> Ultra</b> is the world's best sanding body filler. Its unparalleled sanding qualities are a result of the patented EcoResin <sup>™</sup> . Its non-sag formula has excellent filling properties, while eliminating the need for finishing putty. <b>Rage<sup>®</sup> Ultra</b> contains ZNX-7 <sup>®</sup> and is part of the Metalworks <sup>®</sup> system.		
APPROVED SUBSTRATES:	<ul> <li>Steel</li> <li>Stainless Steel</li> <li>SMC</li> <li>Fiberglass</li> </ul>		<ul> <li>Galvanized Steel</li> <li>Aluminum</li> <li>Sanded OEM Paint</li> <li>Silicon Bronze Welds</li> </ul>

**NOTE:** For structural repairs prone to high degrees of stress and flexibility, use a fiber reinforced filler such as Everglass<sup>®</sup>, Kitty Hair<sup>®</sup> or Fiber Tech<sup>®</sup>.

## PREPARATION:



- Clean and degrease the entire panel to be repaired with soap and water, followed by a mild cleaning solvent. Thoroughly dry the surface before repairing.
- Keep the repair area small. Use 80-180 grit to remove the paint and featheredge with 180.

NOTE:

Smaller repairs on OEM Paint can be prepared with 180 grit

## **MIXING:**

) <b>-</b>	╋

- Stir the filler before using. Knead the cream hardener.
- Measure hardener 2% by weight (add a ribbon of cream hardener from edge to edge across the center of a 4" diameter puddle).
- Puddles larger than 4" (10 cm) in diameter will require additional hardener. Mix thoroughly until uniform color is achieved.

a division of Illinois Tool Works Inc. | 6600 Cornell Road | Cincinnati, OH 45242 | (513) 489-7600 ©2017 Evercoat evercoat.com



## APPLICATION:



- Apply in layers with even firm pressure.
- Do not apply all at once.

FINISH:	<ul> <li>Sand body filler with 80-180 grit sandpaper.</li> <li>If necessary, re-apply Rage<sup>®</sup> Ultra to fill any pinholes or low spots, allow filler to dry and then sand with 180 grit sandpaper.</li> <li>Finish sand with 180 grit.</li> </ul>		
NOTE:	* Allow minimum of 20 minutes sanding time over silicon bronze welds. For optimum performance apply 440 Express before applying primer surfacer.		
TECHNICAL SPECIFICATIONS:	<ul> <li>Appearance</li> <li>VOC</li> <li>Relative Density</li> <li>Sand Time</li> <li>Max Recommended Thickness (sanded)</li> </ul>	Off-White paste Refer to Section 9 of the Safety Data Sheet Refer to Section 9 of the Safety Data Sheet 15-20 min. 1/4 inch (6mm)	
NOTE:	Properties are typical values and should not be considered as sales specifications. Physical testing performed @ ~72°F (22°C) / 75% RH unless otherwise noted.		
SAFETY &	Dood all directions and warnings price	or to using Evergent® producto	

- HANDLING:
   Read all directions and warnings prior to using Evercoat® products.

   Safety Data Sheets can be found online at evercoat.com.
- NOTES: Never return mixed filler to can

Keep can closed and store in a cool dry place

USE WITH EVERCOAT CREAM HARDENER ONLY!

a division of Illinois Tool Works Inc. | 6600 Cornell Road | Cincinnati, OH 45242 | (513) 489-7600 ©2017 Evercoat evercoat.com

> 100-131-100125-TDS 7.2017