



2015-2017 Mustang Mirror Block-Offs





- Remove the two screws holding the bottom portion of the door panel.



- Using a 90° pick tool, remove the back panel behind the door handle. Gently pry the indicated.
- Remove the bolt securing the door panel.



- Bring up the window roughly two inches from the fully open position.
- Gently remove the window switch panel by pulling upwards. The use of a plastic prying tool is suggested.
- Remove the last bolt securing the door panel.
- The door panel can now be pulled off by slowly working your way around.
- Disconnect all connectors and door latch cable.



- Temporarily remove the factory speaker.



- Unclip the mirror harness from the door frame by accessing the speaker hole.



- Peel back the tape to access the 3 nuts holding down the mirror.



- Slightly enlarge the three holes pictured to give more clearance. Fitment varies from one car to another.
- Install the mirror block-off and tighten to 89 inch/pound. Make sure to use blue Loctite® upon installation.
- Reassemble and repeat for the opposite side.