

ARMORDILLO GUARDS

GC-SVL-97-3

Coupler Guard Installation Guide



Outside View - Closed View



Outside View - Open View



Inside (Cab side) View

Qty	Item Description
1	8" Long Foam Strip (2" x 1/8" x Thick)
2	Male Hinges - Main Body
2	Female Hinges - Door Lid
4	1/2" x 1" Bolt, Lock Washers & Flat Washers
2	1/2" x 1" Serrated Flange Bolt
8	5/16" x 1" Nut, Bolt, Lock Washers & Flat Washers

Installation Tips

- Save all factory bolts for guard installation.
- Guard should be installed unassembled.
- Leave all hardware hand-tight until bolts are installed.



Measure Distance where to place the foam strap.



A Closer Look @ the Ruler



936.894.2060 ARMORDILLOGUARDS.COM