

# ARMORDILLO™ SSV LIGHT GUARD INSTALLATION



1. Remove factory grommets from roof holes.
2. Install guards as shown with bolts provided.
3. Keep working after dark and get the job done!



**Keep skid steers on the job & save repair costs!**

Thank you for your purchase! See what else we offer on our website, Facebook, and YouTube.



936.894.2060 [ArmorDilloGuards.com](http://ArmorDilloGuards.com)