## ARMORDILLO SVL FUEL CAP GUARD INSTALLATION



- 1. Remove (2) existing bolts below fuel filler cap.
- 2. Remove fuel cap.
- 3. Place guard over filler neck.
- 4. Replace (2) bolts and tighten.
- 5. Replace fuel cap.

## Keep skid steers on the job & save repair costs!

Thank you for your purchase! See what else we offer on our website, Facebook, and YouTube.







