

ARMORDILLO™ QUICK TACH GUARD INSTALLATION

- See pictures for part orientation and placement.
- Guard assembly is in three pieces and should be installed one piece at a time.
- NOTE: two guard halves, one large, one smaller.
- Leave all hardware hand tight until all bolts are installed.



1. Tilt Quick Tach Assembly until approximately level.
2. Slide large half over factory boss, making sure the notches in pipe go over factory boss as shown.

3. Repeat for smaller half. Tilt or rotate halves so that loose end of 1" stud inserts into smaller half.

Flip page for more directions!

Keep skid steers on the job & save repair costs!

Thank you for your purchase! See what else we offer on our website, Facebook, and YouTube.



936.894.2060 ArmorDilloGuards.com

SVL Quick Tach Guard Installation Instructions

Continued



4. Hand tighten 1" hex nut. Lock washer should be on shorter half side.



5. Install "T" shaped splice bracket as shown. Toe of top flange should face cab. ** Note: Stand-off plates should engage factor cross member approximately as shown in end view.

6. Install all 1/2" hardware as shown. Nuts and lock washers go to cab side. Bolt head and flat washer to opposite side.

7. Torque 1/2" nuts to 50-60 lb. foot. Tighten 1" hex nut.



936.894.2060 ArmorDilloGuards.com