

# TM ARMORDILLO SVL REAR DOOR SCREEN INSTALLATION



1. Guard should be installed with slide latches loosely attached.
2. See latch orientation in photos for reference of upper and lower placement during installation.
3. Hold guard in position as shown and slide latches into upper and lower slots as far as latch will engage.
4. It will be necessary to move guard up and down as required to allow latches to engage properly.
5. Sufficiently tighten all bolts until lockwasher is fully engaged.
6. Guard is designed for simple installation and removal to facilitate cleaning.



**Keep skid steers on the job & save repair costs!**

Thank you for your purchase! See what else we offer on our website and Facebook.



936.894.2060 [ArmorDilloGuards.com](http://ArmorDilloGuards.com)