

ARMORDILLO REAR HOOD GUARD INSTALLATION



1. Open rear access door. Slots in guard should align with those in door top.
2. Position (4) carriage bolts, threads up.
3. Install (4) 1/2" 13NC hex nut, lock washer and flat washer, and tighten until gasket is almost fully compressed.
4. Hardware position as per picture should yield optimal guard strength and function.

Keep skid steers on the job & save repair costs!

Thank you for your purchase! See what else we offer on our website and Facebook!



936.894.2060 ArmorDilloGuards.com