

ARMORDILLO GUARDS

GLF-SVL-75-3/97-3 & GLR-75-3/97-3

Front & Rear Light Guard Installation

Pre-Installation:

- Remove (3) factory bolts on the sides of each light and set aside.
- Remove and unplug lights and set aside.



Installation:

- Install (2) ½"-13x1" Hex-Head Bolts, Fasteners, and Locknuts as shown.
 - Do not tighten until all bolts are started.
- Use Socket-Head Bolts on the lower side holes for arm clearance.
- Tighten all bolts.
- Reinstall lights and factory bolts.



936.894.2060 ARMORDILLOGUARDS.COM