

ARMORDILLO GUARDS

GC-SVL-75-3 INSTALL GUIDE



➤ Remove factory cover - bolts to be reused

➤ Remove inner manifold mounting bolts - to be reused

➤ Measure and mark the protective location

*This dimension is 12 5/8" from rearmost hole on the outer mounting bracket to forward-most edge of foam strip



936.894.2060 ARMORDILLOGUARDS.COM

ARMORDILLO GUARDS

GC-SVL-75-3 INSTALL GUIDE



- Apply adhesive backed foam as shown
- Install ArmorDillo Guard as shown. Retain factory bolts cab side and offside
 - *Install hardware hand-tight until all fasteners are started
 - *Factory manifold tends to twist a bit when inner bolts are removed - be patient
 - *Sometimes it helps to loosen the bolts that hold the manifold bracket to the loader arm (cabside)
- Slide Guard as far rearward as possible to engage arm
- Tighten all bolts



936.894.2060 ARMORDILLOGUARDS.COM