Ground Disturbance

The purpose of this safe work practice is to protect workers from injuries from ground disturbance. Compliance with this program is mandatory and is applicable to all employees.

Definitions

"Ground disturbance" is when work operations or activity on or under the existing surface results in a disturbance or displacement of the soil.

Ground disturbance is not hand digging to a depth of no more than 30 cm below the ground surface, so long as it does not permanently remove the soil cover over the buried facility.

Client Responsibilities

Clients are responsible for deciding where the proposed drilling will take place. The client is required to expose any buried facility within 5 metres of a borehole.

Company employees on site will ensure there is no drilling performed unless all underground utilities are properly located and marked. Drilling is not permitted within 5 metres of a buried facility unless it has been exposed to sight:

- By a non-destructive technique acceptable to the owner of the buried facility.
- By an equivalent method.
- By hand digging.

Responsibilities

Employees are required to:

- Perform a safety meeting/toolbox box talk before proceeding with ground disturbance.
- Ask the client for proper paperwork for underground facility marking/location.
- Not perform any ground disturbance or drilling if locating of underground facilities has not been accomplished.
- In cases where clients insist that drilling or disturbing of ground occurs without proper paperwork, employees are to inform their supervisor or Operations Manager immediately, and not drill.

Preparation

Before the ground is disturbed all underground utilities are required to be located and marked. It is the responsibility of the client to:

Contact the owner or owners designate of:

- A pipeline that is within 30 metres of a borehole location.
- Any other buried facility that may be affected by ground disturbance.
- Advise the owner of the proposed activities.
- Ask the owner to identify and mark the location of buried facility.
- Not begin disturbing the ground until the buried facilities are marked.
- Have a permits in place, such as a proximity agreement or crossing agreement, for completion of ground disturbance, if required by the owner.
- If the client is not on site, notify the client prior and upon completion of the drilling / backfilling of the boreholes.

ABC Inc. 6