



Typical Installation Guide

- **Dig hole** 300mm wider than base of pier.
Depth dependent upon pier loading and ground condition.
- **Preliminary cast** [1]; pour concrete into base of hole and allow to cure.
Shutter if necessary
Mix of concrete and depth of hole dependent upon pier loading.
- **Position pier** on cast pad.
- **Drill hole** in base of post/beam and **locate onto pier** [2].
- When layout is complete, **cast secondary layer** [3] locking pier into final position.
- Cover with **finishing surface** [4].

