

**Parts List:**

- (1) Float Plate
- (1) Wooden Handle
- (2) Screws
- (2) Nuts

**Tools Required:**

- Phillips Screw Driver
- 3/8<sup>th</sup> Socket or Pliers

**Some Assembly Required:**

1. Place the Handle on the smooth side of the Float Plate.
2. Line up the holes on the handle and the Plate.
3. Insert Screw from the Plate bottom up through the handle.
4. Screw on the nut and use tools to tighten till fully tighten.

**Prepping your Float:**

- Take some wet concrete, put concrete on the bottom of the Float to fill in the Grooves.
- After sitting for one hour, take a towel and wipe the bottom of the Float to remove excess concrete. (the Grooves should be almost filled).
- Let the float sit overnight and it's ready to use the next day.